


**Model FCAT GPS-01
INSTALLATION AND OPERATING INSTRUCTIONS**



PARTS LIST

quantity	description
1	Firecat GPS Power Unit p/n #800-0001-0
4	Cable Ties
1	installation guide
1	Tube of Silicon Dielectric Grease

Tool / Material LIST (not provided)

- T27 Torx bit
- Isopropyl alcohol / swab

These instructions are for the installation of the CyBurg Technologies Model FCAT GPS-01 in an Arctic Cat Firecat snowmobile. Installation in other snowmobiles will vary depending on the model.



Verify ignition is OFF and, if equipped, the battery is disconnected before performing installation.

Installation:

1. Open the hood. Swing the belt cover out of the way. The power accessory plug is a two-pin plug with yellow/brown wires located along the steering column behind the dashboard. It can be buried pretty deep in the wire harness. The plug can be viewed behind the servo motor. Better access is provided if the servo motor is removed from the dash board using a T27 Torx to remove the two retaining bolts.
2. Remove any protective dummy plug or existing accessory plug from the accessory plug. To lubricate and seal the connectors, apply silicon dielectric grease (supplied) to the contacts and connector housing. Attach the longer of the two Power Module power plugs into the snowmobile accessory plug.
3. If needed, remove the protective black plastic cap and attach any existing accessories (helmet shield heater, digital gauges, etc.) to the shorter SAE 2-pin plug.
4. Clean the area of any grease or dirt behind the dash using isopropyl rubbing alcohol. Remove backing from the double sided tape on the back of the Power Module and mount the unit to the back of the dashboard near the steering column. Use cable ties as needed to dress and secure any loose wires.





5. Route and secure the USB Cable along the steering column and handle bars to the GPS unit. Bundle any extra USB cable with a cable tie behind the dash. **DO NOT PLUG THE USB PLUG INTO GPS UNIT AT THIS TIME.**
6. Start the snowmobile and verify the red indicator light is lit on the power unit. If not, turn off snowmobile, check connections and verify there is AC power available to the accessory plug.
7. Start the snowmobile, plug the mini-USB plug into the GPS unit. The GPS should display an AC plug symbol indicating it is operating on AC power. When you turn off the snowmobile, the GPS unit will prompt if you want to turn off, or switch to battery power.
8. Setup the GPS unit: Depending on your GPS Mounting hardware, engine vibration can cause the electronic compass to swing erratically. **For Garmin Oregon:** Disable the electronic compass by - (Setup>Heading>Compass>Off). Since the GPS unit is operating on snowmobile power, you can turn off the Backlight timeout (Setup>Display>Backlight Timeout>Stays On). **For Magellan eXplorist:** Access the Settings Menu > Tap on the Sensors button > Tap the Electronic compass drop-down menu and select "OFF".
9. In the case of a short circuit, the internal resettable fuse will trip. The short must be removed, and the unit allowed to cool down before resuming operation.
10. Although designed to operate at very low-idle speeds, it is possible, depending on electrical loading, for the idle speed to be too low to generate enough power to run the GPS. If the GPS unit power switches on/off erratically, you may have to adjust your idle speed a little higher.

NOTE: The Power Module will not charge NiCad or NiMH batteries that may be installed in the GPS unit.

**CyBurg Technologies, LLC.
Limited Warranty**

What This Warranty Covers

This warranty covers substantial defects in materials and workmanship in your new GPS Power Unit for 90 days from date of purchase.

What This Warranty Does Not Cover

This warranty does not cover any problems which result from improper installation, installation in unapproved snowmobiles or GPS units, abuse, accidents, or acts of God, such as hurricanes or floods. Cut or damaged cables are indication of improper installation. CyBurgTechnologies DOES NOT PROVIDE ANY OTHER WARRANTIES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME JURISDICTIONS DO NOT ALLOW THE LIMITATION OF IMPLIED WARRANTIES, SO THIS LIMITATION MAY NOT APPLY TO YOU. CyBurg Technologies is not responsible for returning to you product which is not covered by this limited warranty.

How Long The Warranty Lasts

The coverage of this warranty lasts for 90 days from date of purchase. A valid proof of purchase may be required to prove eligibility. If you do not have a valid proof of purchase, the limited warranty period will be measured from the date of manufacture.

How To Get Service

To obtain limited warranty service, you must first obtain a Return Materials Authorization and ship-to address by contacting Cyburg Technologies, LLC via email at cyburg@cyburgtech.com. You must return the product in secure packaging as directed in our reply. You must pay any associated transportation charges, duties and insurance in shipping the product to CyBurg Technologies. Cyburg Technologies warrants that the replaced products are covered for the remainder of the original product warranty or 90 days, whichever is greater.

Limited Liability

CYBURG TECHNOLOGIES AND ITS AFFILIATES, SUPPLIERS, DISTRIBUTORS, AND RESELLERS ARE NOT LIABLE FOR ANY OF THE FOLLOWING: 1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES (OTHER THAN BODILY INJURY INCLUDING DEATH AND TANGIBLE PERSONAL PROPERTY; 2) LOSS OF, OR DAMAGE TO, YOUR DATA; OR 3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF INFORMED OF THE POSSIBILITY. SOME JURISDICTIONS DO NOT ALLOW LIMITATION OF LIABILITY, INCIDENTAL DAMAGES, OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. Terms and Conditions of the Warranty and Returns Policy are subject to change without notice.

How State Law Applies

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Arctic Cat® and Firecat® are trademarks or registered trademarks of Arctic Cat Inc. Arctic Cat Sales Inc. is not a successor of Arctic Enterprises, Inc. ©2014 Arctic Cat Sales Inc., 601 Brooks Avenue South, Thief River Falls, MN 56701

Garmin®, Montana®, Oregon® is a registered trademark of Garmin Ltd.

Magellan® and eXplorist® are trademarks of MiTAC International Corporation (Magellan).

Other products or company names mentioned may be the trademarks or registered trademarks of their respective owners.

Copyright ©2014 CyBurg Technologies, LLC

All rights reserved. No part of this document may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of CyBurg Technologies, LLC . .